



# ETIXLIQUID

## DISINFECTANT LIQUID FOR SURFACES BASED ON ETHYL ALCOHOL

Complete virucidal action

Registration of the Italian Ministry of Health number 20675

Ready to use, it dries quickly

### APPLICATIONS

Practical and versatile surface disinfectant that can be used both in everyday life and in hospitals. It is particularly suitable for all those situations in which it is necessary to disinfect all surfaces and objects with which it comes into contact.

### FEATURES

100 g of product contain: ethanol (CAS No. 64-17-5) 70.4 g, excipients and deionized water q.s.

Disinfectant action demonstrated by tests EN14476, EN16777, EN13727, EN1500 and EN13624. Eliminates 99.9% of bacteria, fungi and viruses.

### INSTRUCTIONS FOR USE

Disinfection of hard surfaces, even in hospitals: after having cleaned the surface to be treated with water and detergent, spray the product directly on it and spread evenly, leaving it to act for about 3 minutes. In case of disinfection of surfaces that could come into contact with food, rinse thoroughly with drinking water.

Keep out of the reach of children, keep away from heat sources, in case of contact with the eyes wash immediately with water, in case of ingestion consult a doctor (show the label). Do not use for uses other than those indicated.


Do not use on alcohol-sensitive materials (eg plexiglass).

PACKAGING:	Standard packages	N° pieces for carton	N° cartons / packages for pallet	N° pieces for pallet
	Bottle ml 750	9	72	648
	Tank lt 5	3	48	144

CHEMICAL-PHYSICAL INFORMATION:	Parameters	U.M.	Values	Method of analysis
	Aspect:	-	Liquid	Visual
	Colour:	-	Colourless	Visual
	Perfume:	-	No perfume	-
	Density:	Kg/dm <sup>3</sup>	0,87 ± 0,05	By weighing

HAZARD: Reg. (CE) 1272/2008		H225: Highly flammable liquid and vapor H319: Causes serious eye irritation
	<b>DANGER</b>	

We recommend for use, packaging etc. to follow instruction on label and/or on safety data sheet. This technical data sheet nullifies and replaces any precedent edition.

### Bettari Detergenti s.r.l.

Via Galileo Galilei n.2 - 25020 - Poncarale (BS)  
 Tel. 030-2540330 - Fax 030-2540332  
 info@bettari.it - www.bettari.it  
 Cap. Soc. € 210.000 int. vers. RIEA BS n° 294069  
 Reg. Impr. BS n° 029-29249 - C.F./P.IVA 01428790172